

Corn Row Chicken Coop Manual



Tools Needed:

- Cordelss Drill (12V or higher)
- #2 Square Drive Bit
- Hammer
- Tape Measure
- Speed Square



Little Cottage Co.®
PO Box 455
Berlin, OH 44610
330-893-4212
www.cottagekits.com

© 2008-2009 Little Cottage Co.

Corn Row Chicken Coop Manual



1



Locate 4 wall panels.

2



Locate the 4 pieces for the nest box.

3



Secure with 1 1/4" screw.

4



Continue with walls as shown.

5



Secure with 1 1/4" screws.

6



Set coop on the end as shown.

Corn Row Chicken Coop Manual



7



Install nest floor. Measure 1 1/2" from the opening to the outside of the nest floor.

8



Make sure the floor is flush with the hole as shown.

9



Secure with 2 1/2" screws as shown.

10



Install the nest side panel as shown and secure with 1 1/4" screws.

11



Make sure the opening is flush on the inside as shown and fasten with 2 1/2" screws.

12



Repeat from the opposite side.

Corn Row Chicken Coop Manual



13



Install the back panel. Make sure the top is flush.

14



Next install the nest box lid as shown.

15



Install the aluminum corners on the outside as shown and secure with white trim nails.

16



Locate the outside wall panels as shown.

17



Secure with 2 1/2" screws as shown.

18



Lay on side.

Corn Row Chicken Coop Manual



19



Install top panel.

20



Secure with 2 1/2" screws.

21



Set walls up as shown.

22



Secure with 2 1/2" screws.

23



Next connect it to the enclosed areas as shown.
Keep panel in 1/2" from corner.

24



Secure with 2 1/2" screws.

Corn Row Chicken Coop Manual



25



Repeat from the opposite side.

26



Next install the roof sheeting. Make sure the roof overhang is 1" as shown.

27



Secure with 1 1/4" screw.

28



Repeat from the opposite side.

29



Install aluminum ridge as shown, with white trim nails.

30



Your completed coop!